

# INSTALLATION INSTRUCTIONS

## 7810扶手架安裝說明

1. Disassemble the **Decorative Cover** for installation, as fig# 1 shown.  
將扶手架本體與裝飾蓋分離, 如圖示 1.
2. Located the **Grab Bar** on proper position, as a template to mark drilling centers with pencil as fig# 2 shown.  
將扶手架置放在牆上預定位置, 並畫上鑽孔的記號, 如圖示 2.
3. Use 6mm drilling bit to drill holes 4cm in depth, when mounting on drywall, insert **Plastic Anchors**, then fix **Bracket** to the wall with wall **Screws** Locate the **Decorative Cover** onto the **Bracket** as fig# 3 shown.

當安裝在水泥牆, 使用1/4英寸鑽頭, 鑽孔深度4公分, 填入塑膠塞並使之齊平於牆面, 將固定底座以螺絲鎖在牆面上, 把裝飾蓋套上固定底座, 完成安裝程序. 如圖示 3.

