

Soap Dish

7810-20-80S1

NO	Part NO.	Part Name	QTY
1	0810-A1-5400	Fixing Clip	1
2	0810-A2-54S1	Flange	1
3	0826-2E-7500	Gasket	1
4	0861-X2-4000	Soap Dish	1
5	0802-2A-54S1	Support	1
6	7810-2A-80S1	Ring Holder	1
7	0848-F2-5400	Screw	2
8	0848-F4-38BN	Hex Key	1
9	F026-00-7500	Plastic Anchor	2
10	F026-B2-5400	Fixing Bracket	1
11	F026-06-5400	Screw	1
12	F026-45-5400	Set Screw	1

